

Mini Hi-Fi System with Bluetooth®



Quick Start Guide

- 1** In the box:
- 1 x Mini Hi-Fi System with Bluetooth®
 - 2 x Speakers
 - 1 x Remote Control
 - 1 x AV Cable

- 2** Unpacking
- Carefully take the Mini Hi-Fi System and the accessories out of the box.
 - Check if all items are included in the box.

3 Connections


Speakers

Connect the speaker wire connectors to the speaker terminals located at the back of the unit.

The connectors must be firmly connected to the unit, otherwise there will be no sound coming out of the speakers.

Antenna

Plug in the FM antenna and extend it for FM radio reception.



Right and Left Speaker

FM Antenna Cable

4 Connecting to Power

- When all connections are correctly made, plug the power cord into the mains power socket and turn on the mains power.
- Turn the POWER switch on the back panel to ON and the unit will turn on and go into standby mode.



Getting Started Guide

5 Operating the Unit

- Press the POWER button on the unit or the remote to turn on the Mini Hi-Fi System. Press it again to switch the unit back to standby mode.
- Press the SOURCE button repeatedly to choose the input source. Each press will scroll through the following selection: CD/USB, FM, AUX, LINE IN, BT.

6 Key Buttons and Commands

