Aromatherapy

The device also has a built-in oil diffuser that leaves your smart phone with a pleasant scent when using the aromatherapy function.

Note: If you have a smart phone case, you must remove it during the aromatherapy process.

- Add 1 or 2 droplets (no more than 2) of the desired oil (not included) into the oil diffuser.
- Place your smart phone in the cabinet facing up and close the lid. Press the aromatherapy button to begin the process. The aromatherapy button will light up during the process.
- The process takes approximately 5 minutes and the button light will turn off once completed.
- Press the aromatherapy button to stop the process at any time.

Troubleshooting

	Disinfect button does not light up	Check the device is connected to a 5V/3A power source. Make sure both ends of the micro USB cable are plugged in.
	Disinfect button does not work	Make sure the cover is closed and try again.
	No wireless charging indication on smart phone	Make sure your smart phone supports wireless charging. Make sure the device is connected to a 5V/3A power source.
	No scent after aromatherapy function	Wait approximately 5 minutes for the process to complete. Try again if there is little to no scent.

Specifications

UV type	UVA + UVC	
Wireless charging support	Supports standard 5W/7.5W/10W	
Power input	5VDC 3A	
Built-in USB output	5VDC 1A	
Dimensions (mm)	126(W) x 45(H) x 220(D)	
Weight	350g	

BAUHN

Warranty Information

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion, solely at our option with no charge for parts and labour. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and to compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Repair and Refurbished Goods or Parts Notice

Unfortunately, sometimes faulty products are manufactured, which need to be returned to the supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost. We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 886 649 or write to us at:

Tempo (Aust) Pty Ltd ABN 70 106 100 252 PO Box 6056, Frenchs Forest, NSW 2086, Australia Telephone: 1300 886 649 (Aust) - Fax: (02) 8977 3765 Tempo Help Desk: 1300 886 649 (Aust) (Operating Hours: Mon-Fri 8:30am-6pm; Sat 9am-6pm EST) Email: info@tempo.org

BAUHN



UV Phone Sanitiser with Wireless Charging

User Guide



AFTER SALES SUPPORT

info@tempo.org

Model: AUVPS-0620

Product Code: 702666 06/2020

8 9 10 🛣 🐠 1300 886 649

Product Overview





- 100% LFD indicator
- 2. 75% LFD indicator
- 3. Disinfection timer indicator
- 4. 50% LFD indicator
- 25% LFD indicator
 - 6. Disinfect button
 - 7. Aromatherapy button
 - 8. DC IN port

Note: The images used in this guide show the black colourway of the product. Please note that the functions and operations of the white colourway are the same.

Operation

Power on

Connect the supplied micro USB cable to the DC-IN port of the product and to your 5V/3A power source (not included).

Disinfection

Note: If you have a smart phone case, you must remove it during the disinfection process.

The indicators will light up. Press the disinfect button to enter disinfection mode.

Place your smart phone in the cabinet and close the cover to start the process.

Press the disinfect button again to switch between different times.

The colour of the disinfection timer indicator illustrates the selected disinfection time: Red/Blue/Green - 5/10/15 minutes respectively.

During the process, the % indicators will flash according to the disinfection stage (the 25% indicator will flash when the disinfection is at 0-25% progress and so on). The previous % indicator will continue to light up while the current % indicator flashes.

The % indicators and disinfection timer indicator will turn off when the disinfection process is finished.

The disinfection process will be paused once the cover is opened and the timer will be paused. Close the cover to resume the process.

WARNING: DO NOT directly look at the UV light when the product is on.

Note: The phone must be clean of any dirt or debris to ensure it is properly disinfected. Only surfaces that are exposed to the UV lamp will be disinfected.

Charging your Smart Phone

The device has a built-in wireless charger to charge your smart phone. It also has a built-in USB port to charge smart phones that aren't compatible with wireless charging.

Wireless charging:

Note: If you have a smart phone case, you must remove it when charging.

Place your smart phone in the cabinet facing up to start wireless charging, and make sure that the centre of your smart phone is on the wireless charging icon.

USB charging:

Use your smart phones supplied USB cable to connect your smart phone to the built-in USB port in the product to start charging.

Notes:

- You cannot use the wireless charging and USB charging function at the same time.
- To achieve fast charging for both Android and Apple devices, the product needs to be connected to a 5V/3A or a higher output wall charger (not included).



Warranty returns

Should you for any reason need to return this product for a warranty claim, make sure to include all accessories with the product.

Product does not work?

If you encounter problems with this product, or if it fails to perform to your expectations, make sure to contact our After Sales Support Centre on 1300 886 649 before returning it to the store for a refund.