


Hey!  
Let's get your new soundbar  
ready to use, fast!

## 1 Have you got everything?



Unpack the box (be gentle) and make sure all of these items are there:

- A. Soundbar
- B. Wireless Subwoofer
- C. Remote Control
- D. Wall Brackets (2)
- E. Base Stands (2)
- F. RCA to 3.5mm Audio Cable
- G. 3.5mm to 3.5mm Audio Cable
- H. AC Adaptor
- I. Rubber Feet (3)
- J. Warranty Certificate
- K. General Safety Warnings
- L. Quick Start Guide
- M. User Manual

## 2 How to install

Display and use your soundbar in a way that suits your space, with these different installation options:

### Vertical

Attach a stand to each of the two separate pieces and twist to secure.

### Horizontal

Align the two separate pieces and twist to secure. Apply the rubber feet to the bottom of the soundbar.

### Wall mounted


For detailed instructions on wall mounting the soundbar, please consult pages 8-9 of the User Manual.

We recommend wall mounting to be done by a qualified professional. Incorrect installation could result in personal injury or property damage.

## 3 Which plug goes where?

Want to hook up your new soundbar to your TV? Use the basic guide below to see what the plug and port should look like for different connections. You can find more details on these on page 12 of the User Manual.

(Not all cables come with the soundbar, however we have included a RCA to 3.5mm audio cable and a 3.5mm to 3.5mm audio cable for you.)



Use HDMI to decrease clutter and for high quality audio. Make sure you enable ARC on your TV in order to use this.

Use an optical cable for an easy connection with high quality audio capability.

Use an AUX cable for an easy connection with standard quality audio capability for TV and other audio devices.

Connect a USB device, or plug in your USB storage device to play its contents.




Nearly done! Just a bit more on the other side of this page...



## 4

### Get to know the remote

Familiarise yourself with the remote control - you'll be spending a lot of time together.



## 5

### Using your soundbar

Press the  $\psi$  /MODE button on the soundbar or the  $\psi$  button on the remote to switch the soundbar on.

Press the  $\psi$  / MODE button on the soundbar repeatedly or the MODE button on the remote to switch between HDMI (ARC), AUX, Optical, USB and Bluetooth® modes.

Press the EQ button on the remote to select the best preset equalizers for your audio: Standard, Movie (recommended for viewing movies) and Music (recommended for listening to music).

To pair your Bluetooth® device with the soundbar, make sure the blue indicator light is flashing - this means the soundbar is in pairing mode. (If it's not, hold down the PAIR button on the remote until it does). On your device, select 'ASBWS-0620' to pair with the soundbar and start streaming your music to it.

To pair the soundbar with the wireless subwoofer, please refer to pages 14-15 of the user manual.

## ?

### Uh-oh, this isn't right...

Set-up not going smoothly? We've got you!

**We just need you to check a few things first:**

## U

### Is it plugged in?

A new gadget is exciting! So it's easy to forget something simple - like plugging it into the power outlet. Psst... make sure the outlet is switched ON.

## i

### Look at the manual!


More often than not, the answer you need is right there in the User Manual. The troubleshooting section on pages 23-25 may come in handy for tricky stuff.

## ☎

### Ok, time to give us a call

What? You mean the User Manual didn't have ALL the answers? Speak to us! We'd love to help you get up and running as quickly as possible. Call our **After Sales Support** on **1300 886 649**.

Operating hours: Monday-Friday, 8:30am-6pm; Saturday, 9am-6pm AEST



## Your new Soundbar is ready to enjoy!

Well done, you made it.

Now sit back and relax... your new soundbar is automatically covered by a 1-year warranty. How nice!

