




1 Have you got everything?



- A. Wireless Earbuds (pair)
B. Small/Medium/Large Eartips (pair)
C. Wireless Charging Case
- D. Micro USB Cable
E. User Guide
F. Warranty Certificate

Product Overview 2



- A. Charging Points
B. Replaceable eartips
C. Microphone
- D. Multifunction button
E. LED indicator
F. Charging points
- G. Charging LED indicators
H. Micro USB port
(back of charging case)

3 Operation & Charging

Connect to your smart phone

- The earbuds will automatically power on and you will hear "power on" once taken out from the charging case. The LED indicators will flash red and blue.
- On your smart phone, look for "AMPDQ-1221-2E" and connect. The LED indicators will flash blue once pairing is successful.

Operation

- Tap the multifunction button once to answer an incoming call. Tap twice to end the call. To reject an incoming call, tap the multifunction button twice.
- Tap and hold the multifunction button to command Siri or Google Assistance.
- Tap the multifunction button on the left earbud to decrease volume, the right earbud to increase volume.
- Tap the multifunction button twice on either earbud to play/pause music.
- Tap the multifunction button three times on the left earbud to play the previous track, the right earbud to play the next track.
- Press and hold the multifunction button to turn off the earbuds. The LED indicator will turn off and you will hear "power off".
- The earbuds will automatically turn off once placed inside the charging case.

Charging your earbuds

- Place the earbuds into the charging case, ensuring that the charging points of the earbuds are touching the charging points of the charging case. A full charge will take approximately 2 hours.
- During charging, the charging LED indicators on the charging case will light up according to the % charged (25/50/75/100% - all 4 indicators lighting up indicates earbuds are at 100% battery).

Charging your charging case

- Connect the supplied Micro USB cable to the Micro USB port of the charging case and the other end to your power source. When charging, the charging LED indicators on the charging case will light up according to the % charged (25/50/75/100%).
- A full charge will take approximately 2 hours and all 4 LED indicators will turn light up once fully charged.

Troubleshooting

Cannot hear audio through earbuds

- Ensure the earbuds are paired with your smart phone, the LED indicators should flash blue.
- Increase the volume.
- Power off your earbuds then power them on and pair with your smart phone again.

Charging case not charging earbuds

- Ensure the charging case has sufficient battery. If not, please connect to a power source.
- Ensure the earbuds are correctly placed inside and the charging points are in contact.

Mic not working

- Only one (left/right) earbud's microphone will work. Try the other (left/right) earbud's microphone.
- Power off only on (left/right) earbud to use the other (left/right) earbud's microphone.



Specifications

Playback time	2.5 hours
Input	5VDC, 500mA
Battery	3.7V, 30mAh
Charging case battery	3.7V, 400mAh
Dimensions (L) x (D) x (H)	Charging case: 70.5 x 39 x 32 mm
Weight	Earbuds + charging case: 43g

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Hands (IP) Holdings Pty Ltd is under license. Other trademarks and trade names are those of their respective owners.

Give us a call



What? You mean this User Guide didn't have ALL the answers? Speak to us!
We'd love to help you get up and running as quickly as possible.
Call our **After Sales Support** on **1300 002 534**.
Operating hours: Monday-Friday, 8:30am-6pm; Saturday, 9am-6pm AEST

General Safety Warnings

For the safety of yourself and others, follow all instructions and take notice of all the warnings. When adhered to, these safety precautions can reduce the risk of fire, electric shock and injury.

This product complies with Australian Safety standard AS/NZS 62368.1 to ensure the safety of the product.



The RCM is a visible indication of a product's compliance with all applicable ACMA regulatory arrangements, including all technical and record-keeping requirements.

IMPORTANT

Risk of hearing damage: Never place the earbuds into ears BEFORE turning them on, as the sudden volume may be too high and could cause hearing damage.

Keep the earbuds out of ears until you have turned down the volume. Test this by playing the music and holding the earbuds near (but not IN) your ear, as you turn the volume down.

Once the volume is turned down, you can place the earbuds into ears and gradually increase the volume to the desired level.

Plastic wrapping can be a suffocation hazard for babies and young children, so ensure all packaging materials are out of their reach.

To prevent environmental factors (dampness, dust, food, liquid etc.) harming the power bank, only use it in a well-ventilated, clean and dry environment, away from excessive heat or moisture.

Keep the product away from direct sunlight or heat sources.

In case of damage, do not disassemble, repair or modify the product yourself. Contact After Sales Support for advice on repair or replacement, or refer servicing to qualified personnel only.

Children should be supervised to ensure they do not play with the product.

Do not put any object on top of the product.

Do not place or store appliance where it can fall or be pulled into a bath or sink.

This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.

Do not expose the product to microwaves.

Clean using a dry cloth only - do not use water or chemicals.

Keep the product away from oils, chemicals or any other organic liquids.

Use this appliance only for its intended purpose as described in this guide.

Responsible disposal of the packaging

The packaging of your product has been selected from environmentally friendly materials and can usually be recycled. Please ensure these are disposed of correctly. Plastic wrapping can be a suffocation hazard for babies and young children, please ensure all packaging materials are out of reach and are safely disposed of. Please recycle these materials rather than throwing them away.

Responsible disposal of the product

At the end of its working life, do not throw this product out with your household rubbish. An environmentally friendly method of disposal will ensure that valuable raw materials can be recycled. Electrical and electronic items contain materials and substances which, if handled or disposed of incorrectly, could potentially be hazardous to the environment and human health.



CAUTION
The battery in this device is non replaceable.

GENERAL SAFETY WARNINGS

Enjoy using your product!

Well done, you made it.
Now sit back and relax... your product is automatically covered by a 1-year warranty.
How nice!

