



Please read the User Guide

It will help you get the best out of your product.

Still have questions?
Call After Sales Support
1300 002 534
Or visit tempo.org/support

Warranty returns

Should you for any reason need to return this product for a warranty claim, make sure to include all accessories with the product.

Product does not work?

If you encounter problems with this product, or if it fails to perform to your expectations, make sure to contact our After Sales Support Centre on 1300 002 534.

AFTER SALES SUPPORT

1300 002 534

tempo.org/support

Model: AFTWS-0423-R

Product Code: 711952 04/2023

Stopwatch

On the main menu, tap on the icon to enter stopwatch interface. Tap the play icon to start the stopwatch, tap the pause icon to pause and the reset icon to reset the time.

Timer

On the main menu, tap on the icon to enter timer interface. Select from 1/3/5/10 minutes, and the watch will alert when the selected time is up.

Alarm Clock

On the main menu, tap on the icon to view your alarms. Set your alarms on the FitCloudPro app. When the set time is up, the watch will alert. You can set up to 5 alarms.

Find Phone

After your smart phone is connected to the watch, tap the icon and your smart phone will ring or vibrate.

Activity Reminder

Set reminders to notify you to be active. Set the reminder times on the FitCloudPro app and the watch will alert you on the set time.

Drink Reminder

Set reminders to notify you to be hydrated. Set the reminder times on the FitCloudPro app and the watch will alert you on the set time.

Remote Camera

More Setting (iOS)/Universal Setting (Android)"> "Shake photograph". You can now use the watch as a camera remote for your smart phone. Once the smart phone is connected to the watch, shake your wrist to remotely take a photo.

Watch Face Screen

You can change the style of the watch interface. On the main screen, press for the watch face selection page. Swipe left/right for different options, then tap the touch screen again to confirm selection.

Shortcut menu




Swipe down to access the shortcut menu where you can turn on/off do not disturb mode, adjust brightness, enter settings, find phone and view system version.

Settings

On the main menu, tap on the icon to enter the settings menu to change the below: Display, battery, vibration intensity, language, QR code, password, system.

Change The Straps



Change The Straps

Turn the watch over, push the needle as illustrated below to take off the original strap, then fit the new strap.

Warning

The chain strap consists of a magnet which in close proximity to other metallic objects, may become attached and/or loosen the strap.

Specifications

Display	1.3", 360 x 360 pixels
Ingress protection	IP68
Charging time	2 hrs (approx.)
Charging base input	5V=130mA
Bluetooth Range	< 10m
Built-In Battery	Li-ion 3.7V 200mAh
Weight	40g (approx.) (silicone strap)
Dimensions (mm)	44.6 (W) x 44.6 (H) x 9.5 (D)

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Hands (IP) Holdings Pty Ltd is under license. Other trademarks and trade names are those of their respective owners.

Notes



BAUHN®

Warranty Information

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion, solely at our option with no charge for parts and labour. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and to compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Repair and Refurbished Goods or Parts Notice

Unfortunately, sometimes faulty products are manufactured, which need to be returned to the supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost. We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 002 534 or write to us at:

Tempo (Aust) Pty Ltd ABN 70 106 100 252
PO Box 132, Frenchs Forest, NSW 1640, Australia
Telephone: 1300 002 534 (Aust) - Fax: (02) 8977 3765
Tempo Help Desk: 1300 002 534 (Aust)
(Operating Hours: Mon-Fri 8:30am-6pm; Sat 9am-6pm EST)
Email: tempo.org/support

BAUHN®



Smart Watch
with Interchangeable Strap

User Guide



AFTER SALES SUPPORT


1300 002 534

tempo.org/support

Model: AFTWS-0423-R

Product Code: 711952 04/2023

Parts of the watch



1. Touch screen
2. Side button
3. Charging pins
4. Heart rate, blood pressure and oxygen sensor

NOTE: The images in this guide are for reference only. Your watch may be a different colour.


First Time Use

Charge your watch before using for the first time, you will need to charge it for about 2 hours.

2

Charging steps:

1. Align the charging pins on the back of the watch to the charging pins on the charging cable. It will snap into position once correctly aligned.
2. Connect the charging cable to a USB charging adaptor (not included) or a USB port on your computer.



3. Once fully charged, unplug the charging cable from the charger.

To keep the charging pins clean, please use a damp cloth and gently clean the charging pins weekly.

3

FitCloud Pro App

Search for the FitCloudPro app in the app store to download, or scan the QR code below for installation.



For Android



Google Play and the Google Play logo are trademarks of Google LLC.

For iOS



Apple, the Apple logo, iPhone, and iPad are trademarks of Apple Inc., registered in the U.S. and other countries and regions. App Store is a service mark of Apple Inc.

4

Turn on the Watch

Once the watch is fully charged, press and hold the side button for 3 seconds to turn on the watch. To turn off the watch, press and hold the side button for 3 seconds, and slide "shutdown".

Connect to the App

Open the FitCloudPro app. On the main page, tap "Profile" and set up your account. Select "Device" > "Add device (for Android)", "Add Peripheral Now (for iOS)" > "Search" and it will automatically start to search for nearby devices. On the devices list, select "AFTWS0423R" to connect to the watch. On iOS devices, you may need to tap on "Pair" on a pop up window.

Disconnect from the App

For both iOS and Android devices, open the FitCloudPro app on your smart phone. Tap "Device" and select "Unbind" to disconnect the watch from the app. You will also need to open the Settings menu on your smart phone. Go to Bluetooth settings, tap on the "i" (for iOS) or "setting" (for Android) icon on the right side of "AFTWS0423R" and then tap "Forget This Device" to finish disconnecting.

5

Turn On the Screen

To turn on the screen, press the side button or raise your arm if you're wearing the watch. Press the side button again to enter the main menu. Raising your arm too quickly or slowly may not turn the screen on. The screen will turn off after the preset screen off time.

Functions On the Home Screen

- Swipe right to access the quick menu, weather and sport.
- Swipe left to access sports data, heart rate, weather and sleep monitor.
- Swipe up for the notifications screen.
- Swipe down for the shortcut menu.
- Press the side button to access main menu.

Functions in any Screen


- Swipe right or press the side button to return to the previous screen or main screen.
- Tap on any icon to get into the sub screen.

6

Applications

Please allow permission and enable the notification settings on the respective smart phone application.


Sports

On the main menu, tap on the  icon to enter the multi-sport screen. There are 20 sport modes for you to choose from.

When you want to pause/stop the activity, swipe right and select "Return" to resume or "End" to end the activity. Swipe left from the home screen to view the sports data.


7

Bluetooth Music Playback

- On the main menu, tap the  icon to enter the Bluetooth music playback menu.
- Open the music app on your smart phone.
- Tap play/pause icon to play/pause music.
- Tap previous/next icon to play the previous/next song.
- Tap the Volume Up/Down icon to increase or decrease volume level.


Your smart phone must be connected to the FitCloudPro app to use the function.

Step (Pedometer)


On the main menu, tap on the  icon to measure view data on your steps taken, distance travelled and calories burnt. The watch will record your data automatically. Tap on the touch screen when on the interface to view more detailed data.

8


Heart Rate

On the main menu, tap on the  icon to measure your heart rate. You can also swipe left twice to access the interface. Set measurement intervals and view more detailed data on the FitCloudPro app.

Blood Pressure

On the main menu, tap on the  icon to enter the blood pressure interface. Tap the touch screen to start measurement. Synchronise the data to the FitCloudPro app to keep detailed records.


Blood Oxygen

On the main menu, tap on the  icon to enter the blood oxygen interface. Tap the touch screen to start measurement. Synchronise the data to the FitCloudPro app to keep detailed records.

NOTE: The results and measurements of heart rate, blood pressure and blood oxygen data strictly cannot be used for medical reference and should be used as a reference only.


9

Sleep Monitor

On the main menu, tap on the  icon to view sleep data (you must be wearing the watch during the sleep duration for the function to work). You can also swipe left three times to view the data. View more detailed records on the FitCloudPro app as the data on the watch will be synchronised to the app.

NOTE: If the sleep duration is less than 3 hours, the data will not be recorded.

Weather

On the main menu, tap on the  icon to view live weather. You must be connected to the FitCloudPro app.

NOTE: You must have Internet/mobile connection for this function to work. Your phone location/GPS must also be turned on. The weather displayed may not be the same as your phone's default weather app.

10

Message

After your smart phone is connected to the watch, you can view new messages and other app notifications on the watch. The latest 15 notifications will be displayed on the watch. Your smart phone's "SMS reminder" must be set to on. You can set which app notifications to receive under "App reminder" on the FitCloudPro app.

NOTE: Under "permission settings" on the FitCloudPro app, enable the messages to run in the background.

11