


## **User Guide**

Model: APBMC3-0325-6-W / APBMC3-0325-6-B 6 Way Surge Protection Powerboard



No power output from one of the sockets	<ul> <li>Try other sockets. If the other sockets have power output, it's probably the contact of one faulty socket that is loose or not connected; avoid using that socket.</li> </ul>
No power output from any of the sockets	<ul> <li>Check that the power switch is turned on (you can try to turn it on and off a few times to make sure it's switched on) and that the Active Power LED Indicator is lit green.</li> <li>Check the overload circuit breaker button to see whether it's tripping, push it down to reset the circuit breaker.</li> <li>Make sure the input socket for the power board has power output.</li> </ul>
No output from the USB ports	<ul> <li>Check that the USB cable is connected securely to the USB port and/or try a different USB port.</li> <li>The total output current for the USB ports are 4.5A. Remove devices using the other USB ports.</li> <li>Use another USB cable.</li> </ul>
Power board	<ul> <li>Check that there is no visible damage to the plug or cord.</li> <li>Ensure that the devices connected do not exceed the total maximum</li> </ul>

P is not turning on

- load (2400W, 10A). If exceeded, unplug the devices and press the overload reset button.

## Give us a call




What? You mean this User Guide didn't have ALL the answers? Speak to us! We'd love to help you get up and running as quickly as possible. Call our After Sales Support on 1300 002 534. Operating hours: Monday-Friday, 8:30am-6pm; Saturday, 9am-6pm AEST

## Enjoy using your Powerboard!

Well done, you made it. Now sit back and relax... your Power Board is automatically covered by a 1-year warranty. How nice!





ofter onot eplace laced onnel. uires upport ify the vice it uch of or

