

BAUHN®

STYLUS PEN

Simply unscrew the cap and it is ready to use!



To replace the stylus tip, pull out as pictured below and simply insert the supplied replacement stylus tip.



AFTER SALES SUPPORT



1300 002 534



tempo.org/support

MODEL: AMPDQ-0525S PRODUCT CODE: 719626 05/2025