

BAUHN®

10.1"

WiFi Digital Photo Frame

MODEL: AWDPF-0222

User Manual

AFTER SALES SUPPORT

  1300 002 534



 tempo.org/support

MODEL: AWDPF-0222 PRODUCT CODE: 708522 02/2022

Welcome

Congratulations on your purchase!

This manual tells you all you need to know about using your new BAUHN® product.

Please take special note of any important safety and usage information presented with the  symbol.

All products brought to you by BAUHN® are manufactured to the highest standards of performance and safety and, as part of our philosophy of customer service and satisfaction, are backed by our comprehensive 1 Year Warranty.

Domestic use only: This product is intended for indoor domestic use only. Do not use this product for anything other than its intended purpose, and only use it as described in this manual.

We hope you will enjoy using your purchase for many years to come.

Contents


Welcome	2
Unpack and Prepare	4
Product Overview	5
Operation	6
Troubleshooting	12
Specifications	13
Compliance and Responsible Disposal	14
Warranty Information	15
Repair and Refurbished Goods or Parts Notice	16

Unpack and Prepare


What's in the box

Before setting up your new product, check you have everything:

- A. Photo Frame
- B. Power Adaptor
- C. Desktop Stand
- D. Wall Mount Screw
- E. General Safety Warnings
- F. Warranty Certificate
- G. User Manual



Product Overview



1. **RESET** : using a needle or paper clip, press into the hole to reboot the photo frame to factory settings.
2. **MICRO USB** slot : upload photos from your USB device to the photo frame (cannot be used to connect to your computer). Photos in the USB device cannot be viewed directly onto the photo frame, you must upload the photos to the photo frame. You can also copy photos from the photo frame to the USB device. Note: you will need a Micro USB to USB adaptor (not included).
3. **MICRO SD** slot : insert a Micro SD card to import photos to the photo frame.
4. **DC IN** : connect the supplied power adaptor into the DC IN port and the other end of a power socket to power the photo frame.
5. **POWER** : turn the photo frame on/off. Press once to turn the screen on. When on, press and hold for 2 seconds to open reboot or power off menu. Press and hold for 2 seconds then tap "power off" to turn off the photo frame.
6. **Wall mount holes**.
7. **Stand insert** : slot to insert the included desktop stand.
8. **Speakers** : audio playback for videos.

Operation

Frameo App

Search for the Frameo app in the app store to download, or scan the QR code (right) for installation.



First Time Setup

1. Select language.
2. Connect to your photo frame (you must have mobile internet/Wi-Fi connection).
3. If asked to update to the latest version, please proceed to update.
4. Enter details including your name, location of photo frame and timezone.

Note: USB device will be recognised as “SD card” when inserted into the frame. If both Micro SD card and USB device are inserted, the photo frame will only recognise the Micro SD card.

Photo Sharing

- You can receive photos from a friend and upload onto the photo frame (Your friend must have the Frameo app). On the Frameo app, select the icon and a code will appear.
- Send the code to your friend and once they have added the code onto their Frameo app, they will be able to send you photos.

For Android




Google Play and the Google Play logo are trademarks of Google LLC.

For iOS








Apple, the Apple logo, iPhone, and iPad are trademarks of Apple Inc., registered in the U.S. and other countries and regions. App Store is a service mark of Apple Inc.

Navigating the Photo Frame






1. Add friend - select to generate a code in which your friend can use to send photos to your photo frame.
 2. Settings - open settings menu.
 3. Power - open power menu where you can power off, restart or enter sleep mode.
 4. Hide photo - hide current photo. Display the photo again through the settings menu.
 5. Gallery - open photo gallery
 6. Fit to frame/fill frame - toggle how the photo is shown on the photo frame. Default is fill frame; photo is scaled to fill the entire screen. Fit to frame will ensure the entire photo is shown on the screen.
 7. Adjust photo - automatically adjusts the photo to optimally fit the photo frame. Select to rotate the orientation of the photo.
- Swipe left/right to view your photos.
 - Tap on the screen to access the menu.

Video playback

- Tap the  icon to start video playback. Tap the  icon to pause.
- Tap the  icon to open the volume slider. Use the slider to adjust the volume level.
- Tap the  icon to mute the sound. Tap the  icon to unmute.

Power menu



-  : Power off the photo frame.
-  : Restart the photo frame.
-  : Enter sleep mode.

Settings




On the Frameo app, tap the  icon to enter the settings menu to change the following:

My Frame



- **Frame name** : Change the name of the Frame. This will be the name displayed on the Frameo app of connected friends/family.
- **Frame location** : Change location of frame. This will be the location displayed on the Frameo app of connected friends/family.
- **Set language** : Set the language used on the photo frame.
- **Set time zone** : Set the time zone used on the photo frame.
- **Enable/Disable 24 hour format** : enable/disable 24 hour format display.

Manage Photos

Here, you can view how many photos have been uploaded onto the photo frame and the amount of storage they use. You can also see the amount of storage left on the photo frame.

- Show/hide photos - tap on the photos to hide. The hidden photos will not be deleted from the photo frame and can be shown again. Tap  to hide or show all photos.
- Delete photos - tap on the photos to permanently delete. Tap  to select or deselect all and tap  to delete the selected photos.
- Import photos - import photos from an external storage device (i.e. Micro SD card). Insert an external storage device such as a Micro SD card into the Micro SD card slot of the photo frame. Select the photos to import and tap the  to start the import process. Tap  to select or deselect all photos on the external storage device.
- Export photos - export photos from the photo frame to your external storage device.

My Friends

- Change friend options - tap the  icon to open the friend options menu. From here, you can allow/disallow if a friend may share the code. If enabled/disabled, your friend can receive and share the code to the frame from their Frameo app. On the friends options menu, you can also remove a friend by selecting the DELETE FRIEND button. This will remove the friend from the list and not allow them to send photos to the photo frame. After confirming removing, you can remove all photos previously received from the friend.
- Add person - to add a new person to send you photos, tap the  icon and send the code to your friend.

Display

- **Brightness** : adjust screen brightness.
- **Sleep mode** : sleep mode turns off the display screen to reduce power consumption. Set desired sleep mode start and end time. Sleep mode by default starts at 11pm and ends at 7am the next day.
- Note: you will still be able to receive photos during sleep mode.

Slideshow

- **Timer** : set duration of photo to be displayed on the screen before transitioning to the next photo.
- **Show caption** : set captions on/off. Your friends/family can create captions when sending you photos.
- **Fill frame** : set how the photo is displayed on the frame. Default is set to make the whole photo fit onto the frame. You can also set to make the photo fit inside the frame, adding blurred pixels on the sides or top/bottom.
- **Photo display order** : set order in which photos are displayed on the frame. You can display by date; photos are displayed from latest date or shuffle; photos are shuffled and displayed in random order.
- **Autoplay** : enable/disable autoplay of videos.
- **Video playback** : select how videos are played when autoplay is enabled:
 - Loop videos - video will play on loop until slideshow timer is up.
 - Play once - video will play once and show thumbnail after until slideshow timer is up.
 - Play once and continue - video will play once and after continue to the next photo or video.
- **Video volume** : adjust video volume level.

Wi-Fi

- **Wi-Fi details** : select the ⓘ icon to display details on currently connected Wi-Fi network.
- **Reset Wi-Fi** : select the ⋮ icon to delete all Wi-Fi information and restart the photo frame.

About

- **Android version** : view version of Android installed on the photo frame.
- **Peer ID** : unique ID for your photo frame.
- **MAC** : view MAC address of your photo frame.
- **Frameo version** : view currently installed Frameo version.
- **Up time** : view how long your photo frame has been powered on for.
- **Check for update** : check if an update is available.

Notifications

- **Show notifications** : enable/disable notifications during slideshow.
- **Notification volume** : adjust notification volume level.
- **Storage space** : enable/disable low storage notification.
- **Backup** : enable/disable notification if automatic backup has failed.
- **Network connection** : enable/disable network connection regarding network connection status.
- **New photos** : enable/disable notifications when receiving new photos.
- **New friends** : enable/disable notifications when a new friend has been added.
- **Software update** : enable/disable notifications when a software update has been installed.
- **Feature news** : enable/disable notifications regarding new features.

Backup and Restore

- **Backup frame to external storage** : select to create a backup of your photos, videos, friends and settings to your external storage device. It will also the time of the latest successful backup.
- **Automatic backup** : if selected, the photo frame will automatically backup within 30 hours of receiving new photos.
- **Restore from backup** : before restoring from backup, confirm that your backup is up to date under "Backup frame to external storage". If the last backup is outdated or if no backups have been made, select "backup frame to external storage" to create a new backup. Select "restore from backup" will which restore your frame according to the backup.
- **Reset frame** : permanently remove all data from the photo frame including photos/videos, friends, connection and settings.



Troubleshooting

To keep the warranty valid, never try to repair the system yourself. If you encounter problems when using this unit, check the following points before requesting service.

Problem	Solution
Cannot send photos	Check that the photo frame is connected to the Frameo app with the generated code. Check that you are connected to a Wi-Fi network.
Cannot send videos	Video only supports up to 15 seconds. Videos from Micro SD card or USB to the photo frame are not supported.
Operation issues with Frameo app	Tap "Guide" to open the Quick Start Guide on the Frameo app.
Sound distortion	Adjust to a lower volume level. Take the video through the Frameo app.
Cannot turn on the photo frame	Check that the DC IN connector is securely connected and the AC adaptor is securely connected to a wall socket. Reset the photo frame using a needle or paper clip, press the reset hole to reboot the photo frame.



Specifications

Power Adaptor	Adaptor Input: AC 100-240V, 50/60Hz Adaptor Output: 5VDC, 2A
Operating System	Android 6
Screen Size	10.1 inch
Display	1280 x 800 IPS panel
Aspect Ratio	16:9
Internal Storage	16GB
External Storage	Micro SD/USB supports up to 32G
Wi-Fi	Yes
Picture Format	JPG, PNG
Power Consumption	10W
Dimensions (W x H x D)	263mm x 182mm x 23mm
Net weight	492g

For Technical Support:

1300 002 534

tempo.org/support

Distributed by Tempo (Aust) Pty Ltd,

PO Box 132, Frenchs Forest NSW 1640



Compliance and Responsible Disposal



Packaging

The packaging of your product has been selected from environmentally friendly materials and can usually be recycled. Please ensure these are disposed of correctly. Plastic wrapping can be a suffocation hazard for babies and young children, please ensure all packaging materials are out of reach and are safely disposed of. Please recycle these materials rather than throwing them away.

Compliance

This product complies with the Australian Safety Standard AS/NZS 62368.1 to ensure the safety of the product.

Product

At the end of its working life, do not throw this product out with your household rubbish. An environmentally friendly method of disposal will ensure that valuable raw materials can be recycled. Electrical and electronic items contain materials and substances which, if handled or disposed of incorrectly, could potentially be hazardous to the environment and human health.



BAUHN®

Warranty Information

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion, solely at our option with no charge for parts and labour. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and to compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



BAUHN®

Repair and Refurbished Goods or Parts Notice

Unfortunately, sometimes faulty products are manufactured, which need to be returned to the supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost. We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 002 534 or write to us at:

Tempo (Aust) Pty Ltd ABN 70 106 100 252
PO Box 132, Frenchs Forest, 1640 NSW, Australia
Telephone: 1300 002 534 (Aust) - Fax: (02) 8977 3765
Tempo Help Desk: 1300 002 534 (Aust)
(Operating Hours: Mon-Fri 8:30am-6pm; Sat 9am-6pm AEST)
Email: tempo.org/support

Notes

Notes

Notes

Online support

Visit bauhn.com.au for the latest User Manual for information on the updated features.

Warranty returns

Should you for any reason need to return this product for a warranty claim, make sure to include all accessories with the product.

Product does not work?

If you encounter problems with this product, or if it fails to perform to your expectations, please contact our After Sales Support Centre on 1300 002 534.

ALDI guarantees that our products are developed to our stringent quality specifications. If you are not entirely satisfied with this product, please return it to your nearest ALDI store within 60 days from the date of purchase for a full refund or replacement, or take advantage of our after sales support by calling the supplier's Customer Service Hotline.



AFTER SALES SUPPORT



AUS

1300 002 534



tempo.org/support

MODEL: AWDPF-0222 PRODUCT CODE: 708522 02/2022