



Please read the User Guide

It will help you get the best out of your product.

Still have questions?
Call After Sales Support
1300 886 649
Or visit www.tempo.org

Warranty returns

Should you for any reason need to return this product for a warranty claim, make sure to include all accessories with the product.

Product does not work?

If you encounter problems with this product, or if it fails to perform to your expectations, make sure to contact our After Sales Support Centre on 1300 886 649.

AFTER SALES SUPPORT

1300 886 649

info@tempo.org

Model: AFTWS-0521

Product Code: 705652 05/2021

Sleep Monitor

On the main menu, tap on the icon to enter the Sleep interface. You can track your sleep pattern and view more detailed records on your smart phone once connected to the RDFit app.

NOTE: You must be wearing the watch during the sleep duration for the function to work.

Pedometer

On the main menu, tap on the icon to enter the Pedometer interface. The watch will track the number of steps taken, calories burnt and distance travelled.

Alarm

You can set alarms on the watch. When the set time is up, the watch will alert. Swipe right to stop the alarm or swipe left to snooze.

13

Notifier

After your smart phone is connected to the watch, you can view messages and other app notifications on the watch. The latest 10 notifications will be displayed on the watch.

You can set which app notifications to receive under "push notifications" on the RDFit app.

Find Phone

After your smart phone is connected to the watch, tap on the icon on the watch and then tap the start icon, your smart phone will ring. Tap on the watch again to exit.

Remote Camera

On the RDFit app, go to Device and set "Take picture" to on. Tap on the icon to use the watch as a camera remote for your smart phone. Once the smart phone is connected to the watch, tap the capture icon on the watch screen to remotely take a photo.

14

Weather

Tap on the icon to view live weather (you can see up to a 3 day forecast). You must be connected to the RDFit app and can manually set the city on the app.

NOTE: You must have Internet/mobile connection for this function to work. Your phone location/GPS must also be turned on. You may also need to manually set the city/location on the RDFit app.

Search Device


Under "Device" on the RDFit app, tap "Search device" and the watch will vibrate. Tap "OK" on the watch to stop vibration.

Voice Assistant

Tap on the icon to turn Siri (iOS devices) and Google Assistant (Android devices) on. Speak to the microphone for voice command.

15

Shortcuts menu



Swipe down to access the shortcut menu where you can adjust night mode, lock, brightness, settings, vibration and volume.

Tools

Settings for calendar, stopwatch, sedentary, alarm, app download, calculator and power saving.

Settings

Adjust settings for linking to RDFit app, Bluetooth settings, yoga breathing, clock, notification brightness, sound, volume, display, language, units, motion, power off time, reboot, reset and about.

Watch Face Screen

You can change the style of the watch interface on the RDFit app. Tap "Device" and select "Transmit dials". Select your desired watch screen style and it will be stored under "App download".

Change The Straps

The watch comes with an additional strap for when you want to switch up the styling.



To change the straps, turn the watch over and push the needle knobs to the direction as shown in the illustration.

Take off the straps and fit the new strap.

16

Specifications

Display	1.69", 240 x 280 pixels
Ingress protection	IP67
Charging time	3 hrs (approx.)
Charging base input	5V=180mA
Bluetooth Range	< 10m
Built-In Battery	Li-ion 3.8V 240mA
Weight	50g
Dimensions (mm)	44 (W) x 39 (H) x 11.5 (D)

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Hands (IP) Holdings Pty Ltd is under license. Other trademarks and trade names are those of their respective owners.

NOTE: The results and measurements of heart rate and blood pressure data cannot be used for medical reference and should be used as a guide only.

17



BAUHN®

Warranty Information

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion, solely at our option with no charge for parts and labour. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and to compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

18

Repair and Refurbished Goods or Parts Notice

Unfortunately, sometimes faulty products are manufactured, which need to be returned to the supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost. We recommend you save this data elsewhere prior to sending the product for repair.

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 886 649 or write to us at:

Tempo (Aust) Pty Ltd ABN 70 106 100 252
PO Box 6056, Frenchs Forest, NSW 2086, Australia
Telephone: 1300 886 649 (Aust) - Fax: (02) 8977 3765
Tempo Help Desk: 1300 886 649 (Aust)
(Operating Hours: Mon-Fri 8:30am-6pm; Sat 9am-6pm EST)
Email: info@tempo.org

19

BAUHN®



Smart Watch
with Interchangeable Straps

User Guide



AFTER SALES SUPPORT

1300 002 649

info@tempo.org

Model: AFTWS-0521

Product Code: 705652 05/2021

Parts of the watch



1. Speaker
2. Touch screen
3. Side button
4. Heart rate sensor
5. Charging pins
6. Microphone

NOTE: The images in this guide are for reference only. Your watch may be a different colour.

First Time Use

Charge your watch before using for the first time, you will need to charge it for about 3 hours.

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

296

297

298

299

300

301

302

303

304

305

306

307

308

309

310

311

312

313

314

315

316

317

318

319

320

321

322

323

324

325

326

327

328

329

330

331

332

333

334

335

336

337

338