



Please read the User Guide

It will help you get the best out of your product.

Still have questions?  
Call After Sales Support

1300 002 534  
Or visit [tempo.org/support](http://tempo.org/support)

## Warranty returns

Should you for any reason need to return this product for a warranty claim, make sure to include all accessories with the product.

## Product does not work?

If you encounter problems with this product, or if it fails to perform to your expectations, make sure to contact our After Sales Support Centre on 1300 002 534 before returning it to the store for a refund.

12

## Music Control

You must be connected to the InfoWear app to use this function.

- On the main menu, tap on the icon to enter the Bluetooth music playback menu.
- Open the music app on your smart phone.
- Tap play/pause icon to play/pause music.
- Tap previous/next icon to play the previous/next song.
- Tap the volume icons to increase / decrease volume level.

## Stopwatch

Tap on the icon to open the stopwatch function. Tap the icon to start the stopwatch. Tap the icon to pause. Tap the icon again to record the reading. Press the power button to exit the interface.

13

## Timer

Tap on the icon to enter the timer function. Tap the preset times or set customised time. The timer will automatically start once selected. Tap the icon to pause. Press the power button to exit the interface.

## Find Phone

After your smart phone is connected to the InfoWear app, tap on the icon. Tap "Find Phone" on the watch and your smart phone will ring. Press the power button to exit.

## Shake to Take a Photo

After your smart phone is connected to the InfoWear app, tap "Device" on the app and select "shake to take photos." Your watch will display "shake to take a photo", shake the watch to use as a camera remote for your smart phone.

14

## Alarm Reminder

Set alarm times on the InfoWear app and the watch will alert you on the set time.

## Sedentary Alert

Set reminders to notify you to be active. Set the reminder times on the InfoWear app and the watch will alert you on the set time.

## Drinking Reminder

Set reminders to notify you to be hydrated. Set the reminder times on the InfoWear app and the watch will alert you on the set time.

## Medication Reminder

Set reminders to notify you to take your medication. Set the reminder times on the InfoWear app and the watch will alert you on the set time.

15

## Settings

Tap on the icon to enter the settings menu where you can adjust:

### Watch Faces

Select between the different watch faces.

### Brightness

Adjust screen brightness

### Vibration Intensity

Adjust vibration intensity

### Auto Lock

Select "raise to wake" and auto lock timer

### System Settings

Reboot, power off, reset the watch

### QR Code

Displays the QR code for the InfoWear app.


### About

Device name, version no. and MAC address.

16

## Shortcut Menu

Swipe up from the home screen to access the shortcut menu.



- Vibration intensity - adjust vibration intensity
- Lock screen - locks the screen. Press and hold the power button to unlock
- Screen wake - turn screen wake for 5 minutes on/off
- Settings - enter settings menu
- Power saving mode - turn power saving mode on/off
- Do not disturb mode - turn do not disturb mode on/off

17

## Specifications

Display	1.3", 360 x 360 pixels
Ingress protection	IP68
Charging time	2 hrs (approx.)
Charging base input	5VDC, 180mA
Bluetooth Range	< 10m
Built-In Battery	Li-ion 3.8V 250mAh
Weight	52g
Dimensions (mm)	47(W) x 52(H) x 14(D)

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Hands (IP) Holdings Pty Ltd is under license. Other trademarks and trade names are those of their respective owners.

18

## BAUHN®

### Warranty Information

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion, solely at our option with no charge for parts and labour. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and to compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

### Repair and Refurbished Goods or Parts Notice

Unfortunately, sometimes faulty products are manufactured, which need to be returned to the supplier for repair.

## BAUHN®



### Smart Watch with GPS

#### User Guide



### AFTER SALES SUPPORT

1300 002 534


[tempo.org/support](http://tempo.org/support)

Model: AGPSW-0723

Product Code: 712901 07/2023

19

## Parts of the watch



1. Touch screen
2. Power button
3. Side button
4. Sensor
5. Charging points

## First Time Use

Charge your watch before using for the first time. You will need to charge it for about 2 hours.

2

## Charging steps:

1. Place the watch on top of the cable with the charging points on the back of the watch aligned with the charging pins on the charging cable. It will snap into position once correctly aligned.
2. Plug the USB charging cable into a USB charging adaptor (not included) or a USB port on your computer.
3. Once fully charged (battery icon is full), unplug the charging cable from the charger.

## Turn on the Watch

Once the watch is fully charged, press and hold the power button to turn on the watch.

To turn off the watch, press and hold the power button.

3

## InfoWear App

Search for the InfoWear app in the app store to download, or scan the QR code below for installation.



For Android

For iOS



Google Play and the Google Play logo are trademarks of Google LLC.

Apple, the Apple logo, iPhone, and iPad are trademarks of Apple Inc., registered in the U.S. and other countries and regions. App Store is a service mark of Apple Inc.

4

## Connect to the App

Open the InfoWear app on your smart phone. Once the app is open, follow: Device > Click to add a device > Select "AGPSW0723" from the list. The smart watch will connect to the app. You can also use the InfoWear app to scan the QR code to connect.

**NOTE:** If the connected watch has been reset, please unbind the watch in the app before reconnecting it.

## Disconnect from the App

Open the InfoWear app. Select "Device", tap the connected device then tap "Unbind" to disconnect the watch. On iOS devices, you will also need to open the settings menu on your iPhone. Go to Bluetooth settings, tap on the "i" icon on the right side of "AGPSW0723" and then tap 'Forget This Device' to finish disconnecting.

The InfoWear app supports Android 5.0+ and iOS 11.0+ devices. The watch can only be paired with one device at a time. To pair to another device, please disconnect the current paired device.

5

## Turn On the Screen

To turn on the screen, press the power button or raise your arm if you're wearing the watch.

**NOTE:** You will need to turn on the "Raise to wake" function on the InfoWear app for the function to work.

## Functions On the Home Screen

- Swipe up to enter the shortcut menu.
- Swipe down to enter the message notification interface
- Swipe left or right to access heart rate, sleep data, weather, Bluetooth music playback and pedometer
- Press the power button to enter the main menu.
- Press and hold the power button to reboot, power off or reset the watch.
- Press and hold the side button to quick access the sports interface.
- Press and hold the watch face for 5 seconds to change the interface, swipe left/right to switch and tap to confirm.


6



## Functions On Other Screens

- Press the power button again to return to previous screen.
- Press the side button again to return to home screen.

## Applications

### Workout

Tap on the  icon to enter the workout menu. The watch has 19 workout (sport) modes: outdoor running, indoor running, outdoor cycling, indoor cycling, outdoor walking, outdoor skating, freestyle, basketball, pingpong, football, cricket, badminton, tennis, trail run, trekking, volleyball, rope skipping, climbing machine, yoga and baseball.

Once the desired workout mode is selected, set the calorie target, distance and exercise time by tapping the  icon. Tap the  icon to start the workout mode.

Press the Power button to pause the workout mode.

7

**GPS function:** the watch has a built-in GPS function allowing you to track your distance and other data. When outdoor running, outdoor cycling or outdoor walking mode is selected, the watch will automatically search and record the GPS location. After synchronising with the InfoWear app, you can view more workout records on your smart phone


**NOTE:** Smart phone must have location settings turned on and connected to a mobile network.

Press the Power button to pause the workout mode. Tap the "Stop" icon to save the workout mode data.


GPS searching time is subject to your location and GPS signal. It may take up to a few minutes. If you are inside a building or are underground, the function will not work.

8


## Workout Recording (Activity)

On the main menu, tap on the  icon to enter the workout recording interface. It will display the latest workout recordings.

### Stats (Pedometer)

On the main menu, tap on the  icon to view calories burnt, steps taken and sedentary activity.


### News (Notifications)

Tap on the  icon to view notifications and messages on the watch. It will display up to 10 messages. After pairing with the watch, on your smart phone, select "OK/allow" when asked about the notification function.

Open "Message notification settings" and enable system messages, App messages.

9

## Heart Rate


Tap on the  icon to enter the heart rate interface. Tap on "Tap to measure" to measure your heart rate. You can view more detailed data on the InfoWear app.

**NOTE:** For measurements for heart rate, ensure the following:

- The watch has good contact with your wrist.
- Check that the sensor is clean and there is no dirt or debris covering it.
- The results and measurements of heart rate data cannot be used for medical reference and should be used as a guide only.


10

## Sleep Monitor

Tap on the  icon to view the sleep monitor data (you must be wearing the watch during the sleep duration for the function to work). You can also swipe left/right to view the data. After synchronising with the InfoWear app, you can view more detailed records on your smart phone.

**NOTE:** If the sleep duration is less than 3 hours, the data will not be recorded.

## Weather

Tap on the  icon to view weather forecast. You must be connected to the InfoWear app.

Note: The weather will only display when connected to the InfoWear app. You must have Internet/mobile connection for this function to work. Your phone location/GPS must also be turned on.

11